

Catalogue Spare parts Models 6-10-15-20 EVO

POS.	DENOMINAZIONE
1	Pinion
2	Bearing
3	Spacer
4	Spiral housing
5	Mechanical tab
6	Spiral
7	Pinion
8	Spacer ring
9	Bearing
10	Bowl housing
11	Spacer ring
12	Mechanical tab
13	Bowl
14	Breaking bar
15	Fixed guard
16	Movable grid protection
17	Foot
18	Lower closing panel
19	Basement
20	Hand protection

POS.	DENOMINAZIONE
21	Cover
22	Back carter
23	Mechanical tab
24	Motor
25	Motor pulley
26	Motor pulley washer
27	Engine tie rod
28	Shaft
29	Transmission pulley
30	Belt
31	Transmission pinion
32	Mechanical tab
33	Bearing
34	Seeger ring
35	Chain
36	Transmission shaft
37	Mechanical tab
38	Bearing
39	Flange Bottom Shaft
40	Flange Upper Shaft

POS.	DENOMINAZIONE
41	Spacer ring
42	Sprocket Shaft Top
43	Chain
44	Pusher
45	Touch screen
46	Control panel
47	Microinteractor
48	Support bracket Microinteractor
49	Cam Microinteractor
50	Eccentric pin
51	Led light
52	Temperature sensor
53	Inverter bracket
54	Inverter 110V 50/60 HZ 1PH
55	Inverter 230V 50/60 HZ 1PH
56	Power connector
57	Cable Schuko plug
58	Cable USA plug
59	Cable UK plug
60	Cable Australian plug

